

INDUSTRIAL X-RAY FILM FIXER FOR MANUAL PROCESSOR

PRODUCT CODE	850743 4 x 1.6 litres HDPE bottles
PRODUCT DESCRIPTION	FUJIFILM HiRENFIX I Fixer is high dilution source chemical designed for the processing of Industrial X-Ray Film in manual process.
PREPARATION	To make 5 litres of Fixer: 1) Pour 3.3 litres of water into the appropriate vessel 2) Add 1 bottle of HiRENFIX I to water at 20 degree Celsius and stir thoroughly to obtain a uniform solution
USAGE (MANUAL PROCESSOR)	Recommended processing time is 5 to 10 minutes at 20 degree Celsius. The 5 litres solution has a processing capacity of 100 sheets (24x30cm size film). Note: After development, the use of Stop Bath (3% acetic acid solution) is recommended. It reduces the exhaustion of fixer and prevents fixing faults.
STORAGE	FUJIFILM recommends storage of processing chemicals at 10 to 25 degree Celsius. The lower the temperature, the higher the possibilities of crystallisation of chemical. Oxidisation will occur if the solution is exposed to higher than recommended temperature. For a copy of the Material Safety Data Sheet: http://bit.ly/hirenfix850743

